

## **APPENDIX JJ**

### **VESSEL SUSTAINING CODES (VOYAGE ITINERARY POINT SELF SUSTAINABILITY CODE)**

The vessel sustaining code indicates the physical capability of the ship's gear to discharge the cargo on board regardless of the vessel terms of carriage. This code is used only on the ocean manifest header cards. The most current versions of the following codes are available at the Table Management Distribution System website at: <https://TMDS03.scott.af.mil/>.

**THIS PAGE INTENTIONALLY LEFT BLANK**